

BATTERY BALANCER

The Battery Balancer equalizes the state of charge of two series of batteries, or of several parallel strings of series connected batteries.



Battery Balancer



Battery Balancer



Battery Balancer

The Battery Balancer equalizes the state of charge of two series connected 12V batteries, or of several parallel strings of series connected batteries. When the charge voltage of a 24V battery system increases to more than 27V, the Battery Balancer will turn on and compare the voltage over the two series connected batteries. The Battery Balancer will draw a current of up to 1A from the battery (or parallel connected batteries) with the highest voltage. The resulting charge current differential will ensure that all batteries will converge to the same state of charge.

The problem: the service life of an expensive battery bank can be substantially shortened due to state of charge unbalance

One battery with a slightly higher internal leakage current in a 24V or 48V bank of several series/parallel connected batteries will cause undercharge of that battery and parallel connected batteries, and overcharge of the series connected batteries. Moreover, when new cells or batteries are connected in series, they should all have the same initial state of charge. Small differences will be ironed out during absorption or equalize charging, but large differences will result in damage due to excessive gassing (caused by overcharging) of the batteries with the higher initial state of charge and sulphation (caused by undercharging) of the batteries with the lower initial state of charge.

The Solution: battery balancing

The Battery Balancer equalizes the state of charge of two series connected 12V batteries, or of several parallel strings of series connected batteries.

When the charge voltage of a 24V battery system increases to more than 27,3V, the Battery Balancer will turn on and compare the voltage over the two series connected batteries. The Battery Balancer will draw a current of up to 0,7A from the battery (or parallel connected batteries) with the highest voltage. The resulting charge current differential will ensure that all batteries will converge to the same state of charge.

If needed, several balancers can be paralleled.

A 48V battery bank can be balanced with three Battery Balancers.

LED indicators

Green: on (battery voltage > 27,3V)

Orange: lower battery leg active (deviation > 0,1V)

Orange: upper battery leg active (deviation > 0,1V)

Red: alarm (deviation > 0,2V). Remains on until the deviation has reduced to less than 0,14V, or until system voltage drops to less than 26,6V.

Alarm relay

Normally open. The alarm relay closes when the red LED switches on and opens when the red LED switches off.

Alarm reset

Two terminals are available to connect a push button. Interconnecting the two terminals resets the relay.

The reset condition will remain active until the alarm is over. Thereafter the relay will close again when a new alarm occurs.

Even more insight and control with the midpoint monitoring function of the BMV-702 Battery Monitor

The BMV-702 measures the midpoint of a string of cells or batteries. It displays the deviation from the ideal midpoint in volts or percent. Separate deviation percentages can be set to trigger a visual/audible alarm and to close a potential free relay contact for remote alarm purposes.

SPECIFICATIONS

Battery Balancer		
Input voltage range	Up to 18 V per battery, 36 V total	
Turn on level	27,3 V +/- 1%	
Turn off level	25,6 +/- 1%	
Current draw when off	0,7 mA	
Midpoint deviation to start balancing	50 mV	
Maximum balancing current	0,8 mA (when deviation > 100 mV)	
Alarm trigger level	200 mV	
Alarm reset level	140 mV	
Alarm relay	60 V / 1 A normally open	
Alarm relay reset	Two terminals to connect a push button	
Over temperatures protection	Yes	
Operating temperature	-30 to + 50 °C	
Humidity	95 % (non-condensing)	
Enclosure		
Colour	Blue (RAL 5012)	
Connection terminals	Screw terminals 6 mm2 (AWG 10)	
Protection category	IP22	
Weight	0,4 Kg	
Dimensions (h x w x d)	100 x113 x 47 mm	
Standards		
Safety	EN 60950, CSA/UL 62368-1	
Emission	EN 61000-6-3, EN 55014-1	
Immunity	EN 61000-6-2, EN 61000-6-1, EN 55014-2	
Automotive Directive	EN 50498	

DOWNLOADS

CATÁLOGO GENERAL 2020

 [Catalogo-Bornay-0520.pdf](#) Size: 21.51 MiB